



9822628
Keyswitch Bezel,
OFF/ON



9822641
Keyswitch Bezel,
LIGHT/OFF



9822665
Keyswitch Bezel,
Fan: LOW/OFF/HI



128AD6
Keyswitch Bezel,
Independent Service



32554
Bezel, Run/Stop
Keyswitch, 1.56"H x 2.44"W,
1/4" dia.; mounting holes on
2" centers



32736
Bezel, Independent
Service/On Keyswitch,
1/4" dia.



9753412
Keyswitch Halo



128AC1
Blank Bezel, Black

FIRE SERVICE KEYSWITCH BEZELS



9775614
Red Key Core
Off-On-By-Pass-Fire



9775626
Red Key Core
Off-On-Fire



9821934
Red Key Core
Off-Hold-On-Fire

KEYSWITCH CAMS

Adams part no.	Color	Dover part no.
228AA1	Red	228AA1
228AA2	White	228AA2
228AA3	Blue	228AA3
228AA4	Black	228AA4



228AA1
Cam, Fire Service



9772868
3-Position Rotary Switch
120/230 VAC, 20A



780AC
Return Spring