


CONTACT ASSEMBLY ORDERING INFORMATION		
Adams part no.	Description	G.A.L. part no.
<b>G810C1</b>	Contact assembly for MO interlock, RH, complete; includes canvas/phenolic insulator	INT1H-0024R
<b>G810C2</b>	Contact assembly for MO/MOCP interlock, LH, complete; includes insulator; use with G810C3 RH contact assembly	INT1H-0024L
<b>G810C3</b>	Contact assembly for MOCP interlock, RH, complete; includes canvas/phenolic insulator	INT2H-0018R

*Each contact assembly and contact kit includes all the components shown with its corresponding part no.*

CONTACT KIT ORDERING INFORMATION		
Adams part no.	Description	G.A.L. part no.
<b>G810K1</b>	MO contact kit, RH; includes 1 ea. G810C1 contact assembly, G812C1 MO keeper bridging block, canvas/phenolic insulator, & mounting screws	INT1H-0036R
<b>G810K2</b>	MO/MOCP contact kit, LH; includes 1 ea. G810C2 contact assembly, G812C1 MO keeper bridging block, canvas/phenolic insulator, & mounting screws; use with G810K3 RH contact kit	INT1H-0036L
<b>G810K3</b>	MOCP contact kit, RH; includes 1 ea. G810C3 contact assembly, G812C1 MO keeper bridging block, canvas/phenolic insulator, & mounting screws	INT2H-0017R

## INTERLOCK KITS



INTERLOCK KIT ORDERING INFORMATION	
Adams part no.	Description
<b>G810K4</b>	MOH interlock kit, LH; incl. 1 ea. G810B2 switch housing, G812B2 keeper ass'y., G812LL lower linkage, and G820B2 MOH horizontal release ass'y. INT1H-0002L
<b>G810K5</b>	MOH interlock kit, RH; incl. 1 ea. G810B1 switch housing, G812B1 keeper ass'y., G812LL lower linkage, G812UL upper linkage, and G820B1 MOH horizontal release ass'y. INT1H-0002R
<b>G810K6</b>	MOM interlock kit, LH; incl. 1 ea. G810A2 switch housing, G812A2 keeper ass'y., G812LL lower linkage, and G821A2 MOM vertical release ass'y.
<b>G810K7</b>	MOM interlock kit, RH; incl. 1 ea. G810A1 switch housing, G812A1 keeper ass'y., G812LL lower linkage, G812UL upper linkage, and G821A1 MOM vertical release ass'y.