



GL-850-J



GL-915-C



GL-915-E



GL-915-E3



GL-915-E6



GL-915-L6



GL-930-A4



GL-930-B



GL-930-E



GL-915-P6



GL-915-P9



GL-915-K



GL-915-EE



G30B1



GL-915-TT



GL-915-S

DOOR OPERATOR EQUIPMENT

Adams part no.	Description	G.A.L. part no.
GL-850-J	BEARING, DOOR CLOSER	
GL-915-A4	CAM SET	
GL-915-C	CLOSE ROLLER ASSY	SE5-0022N
GL-915-C7	CAM KIT	
GL-915-E	STOP BUMPER & BOLT	
GL-915-E3	BEARING W/ 2 WASHERS	HWBR-0008N
GL-915-E5	PIN,NYLON-5/32"D x 5/8"	PIN-0044N
GL-915-E6	ARM,DOOR SUPPORT	OP25-0001N
GL-915-EE	OPERATOR CRANK ARM-17" L	OP22-0494N
GL-915-F6	SUPPORT,DOOR DRIVE ARM	OP24-0001N
GL-915-F7	CONN LINK LOWER	
GL-915-K	ARM.OPERATOR ALUM 40" to 49"L	OP22-0216N
GL-915-JJ	CRANK ARM	OP22-0497N
GL-915-L4	NYLON BUSHING	
GL-915-L6	ROLLER BEARING	
GL-915-L7	DRIVE ARM.CROSS PLATE	OP34-0079N
GL-915-LL	ACTUATING LINK & OP.HLD	
GL-915-M5	RUBBER SUPPRESSOR	
GL-915-N	LIMIT SWITCH	OP10-0004R
GL-915-N7	SUPPORT BRKT B/O-B40740	
GL-915-P6	RETRACTING/FRICT. ASSY., LH	SE5-0027L
GL-915-P9	RETRACTING/FRICT. ASSY., RH	SE5-0027R
GL-915-PP	OPERATOR CONNECTNG LINK 17.25" LONG	OP22-0178N
GL-915-R	PILLOW BLOCK	
GL-915-S	BEARING W/ ONE WASHER	HWBR-0009N
GL-915-TT	RETIRING CAM P/U ROLLER	
GL-915-W7	ARM OPERATOR- 34" TO 39"	OP22-0215N
GL-930-A	BASE YOKE ASS'Y RH	CL5-0056N
GL-930-A4	BASE YOKE ASS'Y LH	CL5-0057N
GL-930-A6	GUIDE DOUBLE SPRING	CL5-0059N
GL-930-B	SPRING & SPRNG ROD ASSY	CL5-0051N
GL-930-E	SPRING GUIDE ASSY	CL5-0058N
7263C05H41	DRIVE ARM CROSS PLT.	OP22-0057N
G30B1	GAL BUMPER 1 1/8"DIA x 1/4"L/ 15/32"THRD	



GL-915-N7



GL-915-PP



GL-915-JJ



GL-915-F7



GL-915-L7



GL-915-F6