

## RRB PUSHBUTTON MODULES

2 N.O. Contacts; 2" mounting centers; Button 7/8" O.D.; Halo 1 3/8" O.D.; Black marking on white button; Horizontal or Vertical mounting for buttons only, not for stop switch.

PUSHBUTTON MODULE - RRB	
Adams part no.	Marking
GL-2101-A	B
GL-2101-A1	1
GL-2101-AR	Arrow
GL-2101-DC	Door Close
GL-2101-E4	Blank
GL-2101-X2	Alarm
GL-2101-X4	Emergency Stop Switch-Push To Stop
GL-2101-E1	Emergency Stop Switch-Pull To Stop



GL-2101-A



GL-2101-E1

## SRB PUSHBUTTON MODULES

2 N.O. Contacts; 2" mounting centers; Square Halo

PUSH BUTTON MODULE - SRB	
Adams part no.	Marking
GL-2150-A1	1
GL-2150-A2	2
GL-2150-AR	Arrow
GL-2150-ST	Pull To Stop



GL-2150-ST



GL-2150-A1



GL-933-F6  
RRB Halo-Black



GL-933-F7  
SRB Halo



GL-933-C3  
RRB Halo-White



GL-935-A  
Gong Assembly  
(ref. M6452-3A 110V)

## PUSHBUTTON CAPS - RRB/SRB

Black marking on white button; 7/8" O.D.

Adams part no.	Marking	Type
GL-2000-A3	3	RRB
GL-2000-A4	4	RRB
GL-2000-AG	G	RRB
GL-2000-AR	Arrow	RRB
GL-2000-C1	8	RRB
GL-2000-C2	9	RRB
GL-2000-C3	10	RRB
GL-2000-C4	Blank	RRB
GL-2000-DX	Door Close	RRB
GL-2102-A1	1	SRB
GL-2102-A3	3	SRB
GL-2102-A4	4	SRB



GL-2000-AG



GL-2000-C4



GL-2102-A1