



**REPLACEMENT PARTS FOR OTIS TYPE C6754 AND E6754 RELAYS**

Key no.	Adams part no.	Otis part no.	Description
1	<b>O22D1</b>	154AB1	Carbon contact
	<b>O22D2</b>	154AB2	Graphite contact
	<b>O22D3</b>	150AL3	Copper contact with 3/8" dia. silver tip
2	<b>O22K1</b>	A179AK3	Carbon holder with screw
3	<b>O22K2</b>	A336BR1	Clamp for carbon
4	<b>O22H1</b>	276H1	Bakelite arc barrier
5	<b>O22H2</b>	6534B1	Arc deflector
6	<b>O22C2</b>	—	Movable contact, offset, with 3/8" square copper tip; 2 3/4"L
	<b>O22C3</b>	150Y4/Y8	Movable contact with 3/8" dia. silver tip
	<b>O22C6</b>	153AE8	Movable contact with 7/16" square silver contact; 2 3/4"L
	<b>O22C7</b>	153Z4	Movable contact, offset, without contact; 2 3/4"L
	<b>O22C8</b>	150Y6	Movable contact, offset, with 3/8" dia silver tip; 2 3/4"L
	<b>O22C9</b>	150Y7	Same as O22C8 with silver contact on reverse
7	<b>O22B3</b>	306BR2	Red phenolic base for movable contacts
8	<b>O22R1</b>	141Y1	1"L rivet with cotter pin
9	<b>O22S4</b>	90BB19	Compression spring (make)
10	<b>O22W1</b>	133A6	Spring seat washer
11	<b>O21C4</b>	150P4	Movable contact for auxiliary
12	<b>O21C5</b>	93D2	Support blade for auxiliary
13	<b>O22C4</b>	150C13, 152AN1	Auxiliary stationary contact
14	<b>O22C5</b>	150C14, 152AN2	Auxiliary stationary contact
15	<b>O22W2</b>	128H1	Washer

Key no.	Adams part no.	Otis part no.	Description
16	<b>O22B2</b>	306CJ1	Auxiliary contact base
17	<b>O546B</b>	176KA13	Copper braid connector
18	<b>O521A</b>	175J88	3 3/4"L insulated connector
19	<b>O22T1</b>	464BJ2	Fiber separator, 3 1/8"x5/8"
20	<b>O22AM2</b>	B245AE1	Magnet armature
21	<b>O22AM3</b>	A384FS1	Brass guard
22	<b>O22AM4</b>	384EW3	Phenolic guard
23	<b>O22AM1</b>	B374CP1	Frame assembly with magnet core & washer
24	<b>O22A5</b>	A477BL1	Stop
25	<b>O22S2</b>	90VA16	Kickoff spring for make switches
26	<b>O21P2</b>	99G1	Terminal stud, 1 3/8"L
27	<b>O22P3</b>	99G2	Terminal stud, 2"L
28	<b>O22P1</b>	A433Z1	Panel
29	<b>Hxxxx</b>	222xxx	Coil (see page 216-217)
30	<b>O22K3</b>	179AM1	Stationary contact holder
31	<b>O22C3</b>	150Y4	Movable contact with 3/8" dia silver tip; 2 3/4"L
32	<b>O22J1</b>	6543C	Interlock ("airplane")
33	<b>O22K3B</b>	306CP1	Insulator
34	<b>O22AM5</b>	129BR4	Phenolic washer for coil
35	<b>O21T1</b>	102DA1	I.D. tag
36	<b>O22D4</b>	150W6	Threaded contact with 3/8"-dia. silver tip and jamb nut
37	<b>O22BA1</b>	6810A1	Auxiliary contact assembly without compression spring
	<b>O22BA2</b>	6810A3	Auxiliary contact assembly with O22S5 compression spring
38	<b>O22S5</b>	90LA11	Compression spring for auxiliary contact assembly
39	<b>O22S9</b>	90PA4	Comp. spring for arc deflector