

Carbon Holders



CARBON HOLDERS			
Adams part no.	Carbon size	Stem dia. x length	Otis part no.
O119	5/8" dia.	1/4" x 1 1/4", 1/420 threads	141436
O101	1" dia.	3/8" x 2"	103623
O102	1 1/2" dia.	3/8" x 1 1/4"	105936
O100	2" dia.	1/2" x 1 3/4"	108713
O108	2 1/4" dia.	5/8" x 3 5/8"	106183, 106184

CARBON STARTER, CARBON HOLDER		
Adams part no.	Description	Otis part no.
O138	Carbon starter for O68 copper contact	137726
O150	Carbon holder w/carbon; 1 1/2" x 1 1/2" face; holes 2" center to center	4SW3

DISTANCE PIECES							
Adams part no.	Hex		Stem		Head tap		Otis part no.
	Dia.	Length	Thread	Length	Thread	Depth	
O190	1"	2 1/8"	5/811	3 1/2"	5/811	1 3/4"	127782
O191	7/8"	1 5/8"	1/213	3 1/2"	1/213	1 1/2"	126229
O192	5/8"	1"	3/816	3 1/4"	3/816	1"	127850, 118716

Washers, Nuts & Springs

WASHERS, NUTS & SPRINGS			
Adams part no.	Type of part	Description	Otis part no.
O550	Copper washers	9/16" OD copper washer	127F17
O551		3/4" OD copper washer	127F12
O554		3/4" OD x 9/16" ID copper washer	127F48
O555	Nuts	5/811 brass jam hex nut	68A6
O556		1/213 brass jam hex nut	68A5
O557		3/816 brass jam hex nut	68A3
O559		1/420 brass jam hex nut	68A9
O571	Springs	Bronze hour glass spring	—
O574		Compression spring, 1 1/2"L	—
O575		Compression spring, 1 1/8"L	90LB1
O576		Compression spring, 1"L	90BB1
O577		Compression spring, 1"L	90AB8
O578		Steel spring for Type G switch	92Y1
O582	Compression spring, 2 3/4"L	—	
O584	Compression spring, 2 1/4"L	90JB13	

