


Replacement Coils for Westinghouse Relays



COILS FOR ES AND EST RELAYS						
Adams part no.		Voltage	ES	EST	Westinghouse part no.	
Solder	Plug				Solder terminals	Plug terminals
E1601	E1631	125	•		X19BGG01, G20 X19BGGR1	X19BGG17
E1602	E1632	62.5	•		X19BGG02, G21 X19BGGR2	X19BGG18
E1603	E1633	125		•	X19BGG03, GR3	X19BGG11
E1604	E1634	125		•	X19BGG04, GR4	X19BGG12
E1605	E1635	64	•		X19BGG05, GR5	X19BGG13
E1606	E1636	62.5		•	X19BGG06, GR6	X19BGG14
E1607	E1637	125	•		X19BGG07, GR7	X19BGG15
E1608	E1638	21	•		X19BGG08, GR8	X19BGG16
(3 leads)						
E1611	E1641	125	•		X19BHG1, GR1	X19BHG10
(2 solder lugs, no leads)						
E1621	—	125		Type EC	X19BJG01	
E1622	—	62.5		Type EC	X19BJG02	

COILS FOR KS RELAY				
Adams part no.		Voltage	Westinghouse no.	
2-lead	3-lead		2-lead	3-lead
E1901	E1911	240	X19GG1	X19HG1
E1902	E1912	120	X19GG2	X19HG2
E1903	E1913	300	X19GG3	X19HG3
E1904	E1914	48	X19GG4	X19HG4
	E1915	16		X19HG5
E1906		120	X19GG6	

MISCELLANEOUS COILS			
Adams part no.	Voltage	Ω	Westinghouse part no.
E1662	125VDC	1100	X19BKG02
E1703		104	X19YG03
E1704		1.8	X19YG04
E1706		0.0166	X19YG06

COIL FOR SYNCHRO-DIAL HALL STATION BUTTON ASSY.		
Adams part no.	Voltage	Westinghouse part no.
E1801	n/a	X19ZG11, X19BBG3