



7428C01H02



7652C82H38

PEP BUTTON BRAILLE PLATES

Part No.	Character
7428C01H02	Emergency Stop symbol
7428C01H04	Door Close symbol
7428C01H06	1
7428C01H07	2
7428C01H08	3
7428C01H09	4
7428C01H10	5
7428C01H11	6
7428C01H13	G
7428C01H15	M
7428C01H17	LL
7428C01H22	*1 (Star 1)
7428C01H23	*G (Star G)
7428C01H24	*L (Star L)

Tag 2.50"W x 1.37"H
 Opening for Button 1.125" dia.
 Mounting Holes, SS Character, Black Background.
 Inquire about other characters



7652C81H13

PEP BUTTON BRAILLE PLATES

Part No.	Character
7652C81H02	L2
7652C81H07	M3
7652C81H13	DOOR OPEN F
7652C81H14	DOOR OPEN R

Tag 2.50"W x 1.37"H
 Opening for Button 1.125" dia.
 Mounting Holes, SS Character, Black Background.
 Inquire about other characters

PEP BUTTON BRAILLE PLATES

Part No.	Character
7428C02H22	*1 (Star 1)
7428C02H07	2
7428C02H08	3
7428C02H09	4
7428C02H10	5

Tag 2.50"W x 1.37"H
 Opening for Button 1.125" dia.
 Mounting Holes, BRZ Character, Black Background.
 Inquire about other characters



7428C02H10

PEP BUTTON BRAILLE PLATES

Part No.	Character
7652C82H06	1
7652C82H22	*1 (Star 1)
7652C82H07	2
7652C82H08	3
7652C82H09	4
7652C82H38	7

Tag 2.50"W x 1.37"H
 Opening for Button 1.125" dia.
 Mounting Holes, BRZ Character, Black Background.
 Inquire about other characters



7652C79H09

PEP BUTTON BRAILLE PLATES

Part No.	Character
7652C79H02	Emergency Stop
7652C79H03	Door Open
7652C79H04	Door Close
7652C79H06	1
7652C79H07	2
7652C79H08	3
7652C79H09	4
7652C79H10	5
7652C79H11	6
7652C79H12	B
7652C79H13	G

Tag 2.50"W x 1.37"H
 Opening for Button 1.125" dia.
 Mounting Holes, SS Character, Black Background.
 Inquire about other characters