

# ESCO



EE-1172-D



EE-1172-F



EE-1172-P



EE-180-C4



EE-932-E



EE-960-AC

TIMERS, SWITCHES, RELAYS & ELECTRICAL	
EE-1172-D	TIMER
EE-1172-F	TIMER KIT 120VAC
EE-1172-P	Timer, 2-100 seconds, 115VAC, 1 AMP (replacement for Freeman model 018, 030, 031 and Agastat SSC12ADA)
EE-960-R	TIMER 220VAC 2-267-038 (replacement for Freeman model 019 or Agastat SSC12BDA)
EE-180-B2	SWITCH N.O.
EE-180-B3	SWITCH N.C.
EE-180-C4	MICRO SWITCH
EE-932-E	SWITCH, STOP
EE-964-I	SWITCH 49L100103
EE-964-J	RH SWITCH 49L100102
EE-964-N	MOTOR STARTER SWITCH 49D5468
EE-960-AA	RELAY, PLUG-IN 120VAC 3PDT 10
EE-960-AC	RELAY 115VAC, AH5871
EE-960-E	RELAY 22665-71
EE-960-EE	SOCKET 3-349-001
EE-960-G	RELAY GUARDIAN 8 POINT
EE-960-W	RELAY 22665-70
EE-964-S	OVERLOAD RELAY
EE-965-B	RELAY, MOTOR START-PILO
EE-470-H	TANK HEATER (preset 110 deg)
EE-981-A	OVRLD HEATER H48
EE-950-E	RECTIFIER (PLUG IN)
EE-959-F	TRANSFORMER 3-368-024 Input 440/480/550V. Output 214V
EE-959-G	TRANSFORMER 3-368-002 Input 240/480V. Output 120V
EE-959-I	TRANSFORMER Input 208/220/240/260V. Output 125V



EE-901-BD



EE-959-G



EE-959-I

CAMS, WHEELS, BELTS & MECHANICAL	
EE-1295-A	CAM ASSY. 5" RED
EE-180-A8	CAM, INDEXING RH
EE-180-A9	CAM, INDEXING LH
EE-180-J	CAM 3"
EE-180-L	CAM SHAFT
EE-180-A5	ESCO STAR WHEEL
EE-180-C	WHEEL STEPPING
EE-949-B	SHEAVE
EE-870-B	V-BELT 3V400
EE-870-C	V BELTS
EE-870-D	BELT 3V450
EE-870-E	V BELT 3-053-14
EE-870-H	V-BELT SET(1SET=4BELTS)
EE-870-K	V-BELT SET - 3V600 (1PC = 6
EE-870-L	V DRIVE BELT / 1 BELT
EE-870-A	BELTS
EE-180-A2	SPRING 3-614-001
EE-180-C9	WHITE VANE ASSEMBLY
EE-180-E	STRIKER
EE-180-F	SPRING SELECTOR
EE-180-G	STRIKER, SINGLE ASSM (3-410-001)
EE-180-H	TAPE GUIDE ASSM (0013-016-031)
EE-180-M	FRICTION CATCH
EE-900-F	SWIVEL GUIDE SHOE
EE-948-B	GATE SHOE



EE-180-A5



EE-180-G



EE-180-H